



Very Well Connected™

# INSTALLATION INSTRUCTIONS

## Product

**7160-0036 VEHICLE BASE**

## Revision

Rev.B

## Form

INST-330

**DODGE SPRINTER (2004-2009)**

Printing Spec: PS-001

**MERCEDES-BENZ SPRINTER (2002+)**

**FREIGHTLINER SPRINTER w/BUCKET SEATS (2004+)**



- You must read and follow all of these installation instructions. Failure to follow all of these installation instructions may result in serious bodily injury or death. The installer and user of the Sprinter Van Base are responsible for installing and using Upper Pole, Motion Attachment and Dock or Cradle assemblies outside the airbag deployment zone (See Product Mounting Disclaimer Below)
- Keep these installation instructions with the product and readily available in the vehicle for future reference of other users of the product.
- Additional copies of the installation instructions can be obtained from Gamber-Johnson. If you need assistance or have any questions, call Gamber-Johnson at 1-800-456-6868.
- Do not remove warning label from product under any circumstances.



Move passenger seat forward to gain access to two seatbolts which attach the seattrails to the back of the seat base.

Remove the rear seatbolts, lift the seat slightly and insert one spacer washer between each seatrail and the seatbase

Reinstall the seatbolts.

Move passenger seat backward to gain access to two seatbolts which attach seattrails to the front of the seatbase.

Remove two front seatbolts.



Insert Sprinter base between seattrails and seat base.

2006 and older vehicles use the inner hole pattern, 2007 and newer vehicles use the outer hole pattern.

Position flange on base against seat base and reinstall seatbolts.

Attach DS-STEP base and lower tube assemblies to Sprinter base with supplied hardware.

### Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© Copyright 2013 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868



A LAC-03 support base is strongly recommended for extra stability. Attach LAC-03 support brace between lower tube assembly and seat base.



On 2007 and newer vehicles an existing hole in the seat base can be used as a mounting point.

## ! WARNING !

- The Upper Pole, Motion Attachment and Dock or Cradle should not be positioned in the area where the airbag will be deployed if it is activated. DO NOT position the equipment in front of an airbag. Equipment positioned in front of an airbag can cause serious injury or death if an airbag was activated, such as in an accident.
- If installation of the equipment requires that the equipment be placed in front of an airbag, deactivate the airbag in the vehicle so it cannot be activated in an accident. In order to secure permission for deactivating the airbag in these circumstances, contact the National Highway Traffic Safety Administration at 1-800-424-9393 to gain permission to do so. If you have any questions or need assistance, call Gamber Johnson at 1-800-456-6868.
- High speed vehicle turns may cause a Motion Attachment product to swivel, interfering with the driver or other equipment.



Complete the install by attaching upper pole, motion attachment and dock or cradle assemblies as required.