

# INSTALLATION INSTRUCTIONS

## Product

7160-0190

DS-52 UNDERBODY SUPPORT

## Revision

Rev. A

## Form

INST-434

The DS-52 Underbody Support plate is designed to provide greater stability to the DS-52 and to distribute the clamping load across the vehicle body.

## Hardware

The DS-52 Underbody Support plate is supplied with the following hardware:

1. 4 ea. 3/8x2.00 UNC zinc coated tap bolt
2. 4 ea. 3/8 UNC zinc coated jam nut
3. 4 ea. 3/8 UNC zinc coated nylon lock nut
4. 4 ea. 3/8 zinc coated spring lock washer
5. 8 ea. 3/8 zinc coated flat washer

## Tools Required

Installation of the DS-52 Underbody Support plate will use the following tools:

1. 9/16 wrench
2. A 10-in piece of twine

## Installation

**Caution:** Before drilling holes through a vehicle floor pan inspect the drill locations for wiring, exhaust pipes, drive train components, fuel lines, and hydraulic lines.

The DS-52 Underbody Support plate can be installed in two configurations: 1) Bolts with threads down, or 2) Bolts with thread up.

### **Bolts with Thread Down**

1. After the holes have been drilled for the DS-52 Base drill one additional hole in the floor pan at the center of the hole pattern. (Figure 1)
2. Thread twine through two small center holes in the DS-52 Underbody Support plate and secure the plate in position with the four PEM fasteners aligned with the DS-52 mounting holes.
3. Position the DS-52 and secure per Figure 2.
4. Remove twine.




FIGURE 1

Product Mounting Disclaimer  
Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868




FIGURE 2

#### Bolts with Thread Up

1. After the holes have been drilled for the DS-52 Base drill one additional hole in the floor pan at the center of the hole pattern. (Figure 1)
2. Thread the (4) 3/8x2.00 bolts into the PEM nuts per Figure 3.
3. Thread twine through two small center holes in the DS-52 Underbody Support plate and secure the plate in position with the four bolts aligned with the DS-52 mounting holes.
4. Position and secure the DS-52 per Figure 3.
5. Remove twine.




FIGURE 3