

Very Well Connected™

INSTALLATION INSTRUCTIONS


Product 7160-0419 **CLEVIS**

Revision Rev.C

Printing Spec: PS-001

Form

INST-585



INSTALL ON EQUIPMENT WITH GAMBER JOHNSON SWIVEL PATTERN CUTOUT

- Remove 1/4-20 Lock Nuts (item 1) and Washers (item 2) from Clevis. 1.
- Place Clevis on equipment with Studs (item 3) going through curved slots. Install Washers (item 2) and 1/4-20 Lock Nuts (item 1) on Studs (item 3) and 2.
- 3. loosely tighten.
- Position Clevis as desired and tighten 1/4-20 Lock Nuts (item 1) securly locking 4. Clevis into position.

INSTALL ON RIGID FLAT SURFACE

- Drill two 0.261 (G drill) inch diameter holes spaced 2 inches apart in desired 1. location. Pay attention to orient holes such that Clevis is mounted in required position.
- 2.
- 3.
- Remove 1/4-20 Lock Nuts (item 1) and Washers (item 2) from Clevis. Place Clevis on surface with Studs (item 3) going through holes. Install Washers (item 2) and 1/4-20 Lock Nuts (item 1) on Studs (item 3) and 4 tighten to secure Clevis.

Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program. © Copyright 2012 Gamber-Johnson, LLC