



Very Well Connected™

INSTALLATION INSTRUCTIONS

Product

7160-0875


Revision

B

Form

INST-747

Vertical Console Box - Ford F150 2015+, F250 2017+ Printing Spec:PS-001



1. Remove the (2) 7mm screws in the top dash tray near the windshield. If the vehicle has a speaker in the top dash tray, carefully remove the speaker cover to access the 7mm screws. Remove the top dash tray. See FIG 1.

2. Set the dash tray aside and remove the (2) 7mm screws in the top of the center instrument panel. See FIG 2.

(2) 7mm Screws
Removed Speaker Cover



FIG 1 - Top Tray w/ Optional Speaker




FIG 2 - Top Inst. Panel Screws

Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© copyright 2016 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868

3. Remove the 7mm screw on the driver's side of the bottom trim panel. Carefully remove the bottom trim panel. See FIG 3.



FIG 3 - Dash Panels

4. Carefully remove the center instrument panel and both side panels.

5. Remove the compartment panel by removing the top (2) 7mm screws and (2) 10mm screws, one on each side. This hardware will be reused to attach the console box. See FIG 4.



FIG 4 - Compartment Panel

7. Unplug, then remove the USB and 12V accessory modules from the storage compartment panel. Note: the 12V accessory module must be removed in two pieces, first the metal cylinder, then the plastic face.

8. Place the 12V accessory and USB/AUX modules into the console box. Use the rectangular spacer taped inside the console box to fill the gap on the backside of the USB/AUX module. See FIG 5 for detail. Once the spacer is snapped onto the back, the module should fit snugly into the console box. Reattach the wires once installed into the box.




FIG 5 - USB/AUX Module Spacer Detail

9. Place the console box into position aligning the mounting tabs with the mounts used for the lower compartment panel. Install the console box using the (2) 10mm screws and (2) 7mm screws removed in step 6.

NOTE: Some downward pressure to push the box into the carpet or floor mat may be needed to mount the box low enough in the top slots for the instrument panel to fit above the console box.

10. Reinstall the panels in the reverse order. The bottom trim panel is left out unless modified.



FIG 6 - Installed Console Box



FIG 7 - Cup Holder Comparison

11. OPTIONAL: If installed in a regular cab model or an extended cab without rear heating ducts the bottom fill panel can be installed to fill the gap between the console and the transmission hump. See FIG 6. The filler panel will ship attached with the necessary hardware.

NOTE: if the flip out center seat/console cup holder is to be used in extended cab models a shorter regular cab cup holder will need to be purchased. See FIG 7.