

Product

Revision RFV. C

7160-0889 CROWN PE4500 PALLET JACK MOUNT

Printing Spec: PS-001

Form INST-638



 You must read and follow all of these installation instructions. Failure to follow all of these installation instructions may result in serious bodily injury or death.

• Do not attempt to install while the pallet jack is in motion or powered on.

•Keep these installation instructions with the product and readily available in the vehicle for future reference of other users of the product.

•Additional copies of the installation instructions can be obtained from Gamber-Johnson. If you need assistance or have any questions, call Gamber-Johnson.

Installation:

Before installation begins, power down the pallet then ensure that the power has been disconnected. Unclip the battery cable as shown below:



Product Mounting Disclaimer Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program. © Copyright 2012 Gamber-Johnson, LLC

Remove two bolts holding pallet jack door closed as shown to the right.

With these two bolts, removed the door should swing open.

Locate the horn (shown below). Remove the horn by removing the 9/16" bolt holding it in place.

Remove the power connector bracket that is located between the battery and chasis wall by removing the four self tapping bolts that are holding it in place. On the side where the horn was previously removed, drill out the four holes that the self tapping bolts were in using a 5/16" drill bit. Using the four sets of 1/4 - 20 bolts, washers and nuts, mount the 7160-0889 bracket between the outer wall and the power connector bracket using the drilled out holes.

Reattach the horn with the 9/16" bolt. Close the pallet jack door and reinsert the two bolts to lock the door back in place. Reconnect the power cable.









