



Very Well Connected™

INSTALLATION INSTRUCTIONS

Product

7160-0871

Revision

Rev.A

Form

INST-744

Ford Sedan Police Interceptor Close-To-Dash Mount

Printing Spec: PS-001



- You must read and follow all of these installation instructions. Failure to follow the installation instructions may result in serious bodily injury or death
- DO NOT install or use this assembly in the area in which the airbag on the vehicle may be deployed. The installer and user of this assembly are responsible for installing and using this assembly outside the area in which an airbag may be deployed. (See Product Mounting Disclaimer Below)
- If the installation of the equipment requires that the equipment (or any additional equipment that is added to the installation) be placed in front of an airbag, the airbag should be deactivated. In order to secure permission for deactivating the airbag you must contact the National Highway Traffic Safety Administration at 1-800-424-9393 to gain permission to do so. If you have any questions or need assistance, call Gamber-Johnson at 1-800-456-6868.
- High speed vehicle turns may cause parts of the assembly to swivel, interfering with the driver or other equipment.
- Keep these installation instructions with the product and readily available in the vehicle for future reference of other users of the product.
- Additional copies of the installation instruction can be obtained from Gamber-Johnson. If you need assistance or have any questions, go to www.gamberjohnson.com or call Gamber-Johnson at 1-800-456-6868.
- DO NOT remove the warning label from the product under any circumstances.

Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

copyright 2016 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868

The Ford Sedan Police Interceptor Close-To-Dash mount is designed specifically to mount on a Gamber-Johnson vehicle specific console box (7160-0410) and to attach to the dash of the Ford Sedan.

Installing the mount:

Step 1. Remove the two 1/4-20 x .50 long socket button head machine screws that hold the passenger side of the top plate on the custom vehicle specific console box. Save these screws so they can be used later in step 6.

Step 2. Attach the passenger side console box bracket to the console with two of the 1/4-20 x .88 long socket button head machine screws found in the hardware bag.

Step 3. Repeat steps 1 & 2 for attaching the drivers side console bracket.



Step 1

console box top plate

1/4-20 x .50 screws



Step 2

passenger side console bracket

1/4-20 x .88 screws

Step 4. Remove the (2) black hex head bolts that attach the dash top cover to the vehicle dash with an 8MM socket.

Step 5. Attach the main bracket to the dash with the (2) M6 x 30mm hex bolts and flat washers provided in the hardware bag.

M6 hex bolts and flat washers

dash cover



Step 6. Attach the main bracket to the console box brackets installed in step 2 with two of the 1/4-20 x .50" long socket button head machine screws that were removed in step 1.

Step 7. Attach the custom clevis (7110-1205) with the 3/8-16 x 1.25" long hex bolt, washers, and nylock nut provided in the hardware bag. See next page for exploded view of attachment.



7110-1205 clevis

1/4-20 x .50 screws

Exploded view showing attachment of 7110-1205 custom clevis to the main bracket.

