







UFP-260 INSTALLATION INSTRUCTIONS

| | | | |
|-------------|---|--------------------------------------|---|
| UFP-260 (1) |  | M5 x 14mm Phillips Head Screws (4ea) |  |
| | | M5 Flat Washer (4ea) |  |
| | | M5 Spring Washer (4ea) |  |

1. Place the display on a flat and soft surface and locate the four mounting points (Figure 1).
2. Attach the UFP-260 Mounting Plate to the back of the display using 4 screws (Figure 2). Do not overtighten the screws.

NOTE: The mounting point pattern will not change. Review the parts list and use the corresponding hardware that will be used for your model display (Figure 3).

CAUTION: DO NOT OVERTIGHTEN THE SCREWS.




Figure 1. Mounting Points




Figure 2. Installing the UFP-260



Figure 3. Installation Complete