





UFP-320 INSTALLATION INSTRUCTIONS



1. Invert the flat panel display and place it on a soft, flat surface.
2. Locate the four (4) mounting points that are found on the back of the flat panel display (Figure 1).
3. Align the UFP-320 to the flat panel display mounting points (Figure 2).
4. Use the four (4) M4 x 10mm Phillips head screws to secure the UFP-320 to the flat panel display. Do not overtighten (Figure 3).
5. Mount the flat panel display to the LCD mount that was purchased.




Figure 1. Flat Panel Display




Figure 2. UFP-320 Mounting Points



Figure 3. UFP-320 Installation