

# INSTALLATION INSTRUCTIONS

## Product

**7160-0976 & 7160-0977**

**DUAL ARTICULATING ARM AND CLEVIS**

## Revision

Rev.B

## Form

INST-789

Printing Spec:PS-001

This instruction sheet is for the DUAL ARTICULATING ARM AND CLEVIS.

**THIS PRODUCT IS NOT DESIGNED TO BE USED IN A VEHICLE.**

This mounting system is designed to be used with a variety of Gamber-Johnson products. Installation instructions for other Gamber-Johnson products are provided with each individual product.

This instruction sheet is for the following products:

**Item No. 7160-0976 DUAL ARTICULATING ARM AND CLEVIS (STANDARD)**

**Item No. 7160-0977 DUAL ARTICULATING ARM AND CLEVIS (SHORT)**

Remove the .25-20 nyloc nuts and flat washers from the adapter plate.  
Place the adapter base on the upper pole assembly inserting the threaded studs through the two radial slots.  
Place the washers and lock nuts on the studs and tighten. Unscrew the tilt knob to loosen the clevis assembly and set the amount of tilt. Lock in place by tightening the knob.

