QUICK GUIDE 13.3" TOUCH SCREEN



A. FEATURES

- 1. Touch Screen
- 2. Power Indicator Light
- 3. Auto Brightness Sensor
- 4. Quick Buttons
- 5. Mounting Bolts: 1/4-20 x 0.50"
- 6. Mounting Pattern: VFSA 75mm
- 7. Hanging Bracket: Removable
- 8. Part Number Label
- 9. Ports
 - Power In: 11-16Vdc
 - HDMI
 - VGA
 - Audio Out
 - USB-A 3.0, 1.5A (2)
 - USB-B 3.0
 - USB-C 3.0, 2.0A
- 10. Speakers
- 11. Cable Tie Bracket
- 12. Cables



C. QUICK BUTTONS

Buttons to the left of the logo, from left to right:

Emergency | Source | Menu | Home | Escape

Buttons to the right of the logo, from left to right:

Black Out | Brightness ↓ | Brightness ↑ | Volume ↓ | Volume ↑ | Power On/Off

B. IMPORTANT INFORMATION

- Plug & Play supports Windows (XP or newer), Android, Linux, Mac OS/iOS platforms.
- The Touch Screen is 5-point Capacitive. It will react quickly but will not work with gloves. (Feature 1)
- The Power Indicator Light will change colors to show the power status. No light indicates no power. Red light indicates off. Green light indicates on. (Feature 2)
- The Source button will switch between HDMI, VGA, and USB-C for video input. Use the Menu button to change settings. Use the Volume buttons to move within those options. Use the Menu button to 'select' and the Source button to go 'back'. (Feature 4)
- · Temperature Range:

Operating -20°C to 70°C
 Storage -30°C to 80°C

- FCC, CE, EN62368, RoHS, REACH compliant
- Tested to full Gamber-Johnson rugged standards
- The Hanging Bracket helps hold the weight while mounting the screen to specific Gamber-Johnson clevises. To use other mounting options, remove the bracket. (Feature 7)
- Reference the Part Number Label for product information regarding any service needs. (Feature 8)
- Cables must be zip-tied to the Cable Tie Bracket. See manual online for installation instructions. (Feature 11)

Thank you for choosing Gamber-Johnson for your Touch Screen needs. To learn more visit gamberjohnson.com and search part number 7160-1451.