
# AM100 INSTALLATION GUIDE

Maximum Flat Panel Weight: 100 lb. / 45.5 kg.


# Low-Profile Ultra-Slim Swingout Mount for Flat-Panels






### **Installation Guide**





Template (Qty 1)









M8 x 25mm (Qty 4)



**Universal Washers** (Qty 4)



5/16" Flat Washers (Qty 4)



Depth Measuring Straw (Qty 1)



Green Level (Qty 1)



Finned Anchor (Qty 4)



**Universal Spacers** (Qty 8)



M4 Allen Key (Qty 1)



5/16" x 3" Lag Bolts (Qty 4)



10mm Socket (Qty 1)



M2.5 Allen Key (Qty 1)

### **TOOLS FOR INSTALLATION**





Leveler



Phillips Head Screwdriver



Protective Eyewear



13mm or 1/2" Socket





Socket Wrench



M6 or 1/4" Wood Drill Bit



Portable Drill



3/8" Concrete Drill Bit



Hammer




# **OPTIONAL:** CHANGING THE DEFAULT SWINGOUT PIVOT POSITION Loosen the eight flat screws to disengage the upper and lower chassis. Loosen the set screw (top and bottom) 3 M2.5 Allen Key Put together the mount after adjusting the swing pivot position and recap the plastic plugs. Plastic Left Mid Right (default) Fully tighten all hardware before hanging the mount.



### **Installation Guide**

1

Find the center of the wood studs and mark the wall with a pencil



FOR CONCRETE APPLICATIONS SEE PAGE 6

2

Position the template to the desired location.


Drill into 4 marked mounting points on the wall surface.

# **Wood Application:**


Use 1/4" drill bit


### **Concrete Application:**

Use 3/8" drill bit






















# FASTEN USING (2) M5 FLAT SCREWS TO SECURE THE BRACKET MOUNT PLATE



Small Straw or Toothpick

### **Selecting the Mounting Hardware**


- Insert a small straw or toothpick into the threaded inserts found on the back of the flat-panel.
- Use a pencil to mark the depth of the threaded insert on the small straw or toothpick.
- Mark the straw or toothpick 1/8" above the depth of the threaded insert, as shown in Figure 1.
- 4) Insert the small straw or toothpick into the remaining threaded inserts to compare and verify their depth using the straw or toothpick's 1/8" allowance mark.
- 5) Locate the correct diameter screw for the threaded insert.



If the screw you selected is longer than the 1/8" allowance mark on the small straw or toothpick, as shown in Figure 2 and Figure 3, do not use this screw. The screw length must not bypass the mark.

6) Test each size of the screws provided.


The correct screws should thread easily into themounting point and not pull out when tension is applied.







Screw


Depth Plus 1/8" Allowance





























### PREMIER MOUNTS LIMITED LIFETIME WARRANTY

### What and Who is Covered by this Limited Lifetime Warranty

Premier Mounts warrants all mounting products to be free from defects in material and workmanship for the lifetime of the original installation of the product.

#### What Premier Mounts Will Do

At the sole option of Premier Mounts, Premier Mounts will repair or replace any product or product part that is defective. If Premier Mounts chooses to replace a defective product or part, a replacement product or part will be shipped to you at no charge, but you must pay any related labor costs.

### What is Not Covered: Limitations

Premier Mounts disclaims any liability for damage to mounts, adapters, displays, projectors, other property, or personal injury resulting, in whole or in part, from improper installation, modification, use or misuse of its products.

NOTWITHSTANDING ANYTHING TO THE CONTRARY IN THIS WARRANTY, THIS WARRANTY IS LIMITED TO FIVE YEARS FROM THE DATE OF PURCHASE IN THE EVENT THAT THE WARRANT-ED PRODUCT IS COMMERCIALLY RENTED OUT.

Electrical products and components, such as amplifiers, speakers, motors, switches remote controls and related electrical items, are backed by a 3-year warranty.

Premier Mounts disclaims all other warranties, express or implied, including warranties of merchantability and fitness for a particular purpose. Premier Mounts is not responsible for incidental or consequential damages, including but not limited to, inability to use its products or labor costs for removing and replacing defective products or parts. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

### What Customers Must Do for Warranty Service

If you discover a problem that you think may be covered by the warranty, you must report it in writing to the address below within thirty (30) days. Proof of purchase (an original sales receipt) from the original consumer purchaser must accompany all warranty claims. Warranty claims must also include a description of the problem, the purchaser's name, address, and telephone number. General inquiries can be addressed to Premier Mounts Customer Service at 1-800-368-9700. Warranty claims will not be accepted over the phone or by fax.

Premier Mounts
Attn: Warranty Claim
2620 Palisades Drive
Corona. CA 92882 USA

### **How State Law Applies**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Premier Mounts intends to make this manual accurate and complete. However, Premier Mounts makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Premier Mounts makes no representation of warranty, expressed or implied, regarding the information contained herein. Premier Mounts assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Warranty: http://www.mounts.com/warranty

