
GB-INWAVPLInstallation Guide

Installationsanleitung, Guía de Instalacíon, Guida de Installazione, Guide d'Installation, Installatie gids







GB-INWAVPL

Installation Guide


Installationsanleitung, Guía de Installacíon, Guida de Installazione, Guide d'Installation, Installatie gids

Hardware







The GB-INWAVPL is design to mate inside between 16" (406.4mm) and larger width wood or sheet metal stud walls. The in-wall box can mated to both stud sides or one only depending on the clear space between the studs.



act as install stop guide for wood or metal studs.








GB-INWAVPL

Installation Guide

Installationsanleitung, Guía de Instalacíon, Guida de Installazione, Guide d'Installation, Installatie gids



Power drill driver may require you to pilot drill at a slight angle due to the width on the in-wall box interior.

If you are mounting to only a single stud use two of each screw and follow the same basic procedure as above.

