



Very Well Connected™

INSTALLATION INSTRUCTIONS

Product

7160-0862

Notepad™ V - Q1

Revision

Rev. A

Form


INST-732

Printing Spec: PS-001

Notepad™V - Q1 is set up specifically for the Notepad Q1 at 8.75" depth and 0.75" thick.

The Notepad™V hold-down clips and key lock are designed to securely hold the laptop in the mount and deter theft, not prevent it. Gamber-Johnson recommends taking your tablet out of the vehicle when not in use.

9/64" Hex (Allen) wrench is needed to adjust clip location and position.
7/16" Wrench or Socket is need to attach Notepad™V to Gamber-Johnson Motion Attachments.#2 Phillips screwdriver and a 9/64" Hex (Allen) wrench are need to mount accessories.



Product Mounting Disclaimer


Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© copyright 2011 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868

Vehicle Mounting

The Notepad™V - Q1 is designed to be used with Gamber-Johnson motion attachments, poles and vehicle bases. The Sliding Mount Bar feature allows side-to-side adjustment of cradle to desired mounting position. Four .25 Flat Washers and .25-20 x .62 long Hex Head Screws are supplied in the hardware bag to secure motion attachments to the bottom side of the cradle.



Adjusting Notepad™V - Q1 fine tuning

If the latch on Notepad™V is locked, unlock the unit with the supplied keys. All Notepad™V's are keyed alike. Unlatch by turning the lock body clockwise 90 degrees.

Pull the lock side of the Notepad™V to the right to open the deck.

Loosen adjustment screws securing front clips, rear clips and side clips enough to raise them and move them in the slots.

Seven Vinyl Caps are included in hardware bag to place over clips to protect tablet if needed.



Place the tablet on the Notepad™V - Q1 deck. Slide the tablet tight against the Front Clips. The Front Clips can be adjusted side-to-side and also have a slight amount of vertical adjustment.

Slide the tablet against the Side Clips on the fixed deck. Adjust the Side Clips side-to-side to avoid any needed ports and lower them so the tab will just clear the top of the tablet and tighten. A snug fit is preferred.

Push the right side of the Notepad™V in until the right Side Clips touch the tablet. Adjust the right Side Clips in the same manner as the left side.

After pushing the unit together, (compressing the tablet between the side clips) turn the lock body 90 degrees counter-clockwise to secure the unit.

Adjust the Rear Supports side-to-side and tighten. Adjust the Rear Clips to prevent the tablet from moving back and tighten.



Notepad™V Accessories

7160-0253 Mic Clip Assembly

The Mic Clip Assembly can be mounted on any corner of the Notepad™V - Q1 that does not have another accessory mounted. Remove the two Phillips Flat Head Screws found on the corner.

Place the Mic Clip Bracket over the holes and attach using two #8-32 x .62 Socket Head Screws and two #8 Flat Washers.

Attach the Mic Clip using two #6-32 x .25 Phillips Flat Head Screws



#8-32 x .62 Socket Head Screws
& #8 Flat Washers

#6-32 x .25 Phillips Flat Head Screws

7160-0252 LED Light Assembly

The LED Light Assembly can be mounted on any corner of the Notepad™ V Cradle.

Remove the two Phillips Flat Head Screws found on the corner.

Place the LED Light Assembly over the holes and attach using two #8-32 x .62 Socket Head Screws and two #8 Flat Washers.


The LED is powered using the red and brown wires on the light base. The LED Assembly is designed to operate on 12 VDC.

In a negative ground vehicle:

Connect the RED wire to the positive pole of the vehicle battery or power distribution box.

It is recommended that the supplied fuse holder and 1 amp fuse be installed on the red wire.

Connect the BROWN wire to a suitable chassis GROUND or the NEGATIVE pole of the battery.



#8-32 X .62 Socket
Head Screws
& #8 Flat Washers

The LED has three light options: Red, White/Red and off.